

System Specifications

The memory is 100% compatible with this sytem:

System manufacturer	Acer
Device type	Laptop
Device family	Aspire Notebook
Device series	ES1-533 Serie
Device name	Aspire ES1-533-P6NL
Standard memory	4GB (1x4GB)
Maximum memory*	16GB / 8GB according to manufacturer
Number of memory sockets	1

* The specifications for the maximum memory upgrade may differ from those of the manufacturer Acer. Often the information given in the manual for the maximum memory upgrade is not up to date. New memory technologies, bios updates or newer software versions often allow the use of memory modules with a higher capacity than specified by the manufacturer with the same performance and stability.

Memory modules with our overRAMing-symbol are approved by us for maximum memory expansion.

Information on memory installation

- Turn off the system
- Remove the plug of the power supply unit (if connected)
- Remove the battery, according to the user manual of the system
- Always ground yourself before touching electronic components
- Protect the memory module from static voltages:
 - Do not touch the gold pins of the memory module
 - Only touch the sides of the memory module
 - Use a grounding strap and/or ESD glove if possible

General installation instructions are supplied by E-Mail.

